

TAB 30

Tablet Instructions

Android™11

Content

1 General Information.....	4
1.1 Profile.....	4
1.2 Safety warning and Attentions	4
2 Your phone	5
2.1 Functions of Keys	5
2.2 Functions of icons.....	6
3 Getting started.....	6
3.1 Charging the Battery	6
3.2 Linking to the Networks and devices.....	7
3.3 Using the touch screen.....	8
3.4 Using the onscreen keypad	9
4Using the Menus	9
4.1 Backup Restore	9
4.2 Browser.....	9
4.3 Calculator.....	10

4.4 Calendar	11
4.5 .Camera	11
4.6 Clock	11
4.7 Downloads	11
4.8 Email	12
4.9 Facebook	12
4.10 File manager	13
4.11Google	13
4.12YouTube	13
4.13GooglePlay	13
4.14Search	13
4.15Settings	13
4.16Sound Recorder	14
4.17Video player	14

1General Information

1.1 Profile

Please read this pamphlet carefully in order to make your tablet pc in perfect condition.

Our company may change this mobile tablet without prior written notice and reserves the final right to interpret the performance of this mobile phone.

Due to different software and network operators, display on your tablet may be different, refer to your tablet for details.

1.2 Safety warning and Attentions

Safety warning

➤ ROAD SAFETY COMES FIRST

Do not use a hand-held tablet while driving. Use hands-free fittings when calls are unavoidable while driving. In some countries, dialing or receiving calls while driving is illegal!

➤ SWITCH OFF IN AIRCRAFT

Wireless devices can cause interference in aircraft. Using a mobile tablet in flight is illegal and risky.

Please make sure that your mobile tablet is powered off in flight.

➤ SWITCH OFF BEFORE ENTERING RISKY AREAS

Strictly observe the relevant laws, codes, and regulations on the use of mobile tablets in risky areas. Turn off your mobile tablet before entering a place susceptible to explosion, such as an oil station, oil tank, chemical plant or a place where a blasting process is under way.

➤ OBSERVE ALL SPECIAL REGULATIONS

Follow any special regulations in force in any area such as hospitals and always switch off your tablet whenever it is forbidden to use it or, when it may cause interference or danger. Properly use your mobile tablet near medical apparatuses, such as pacemakers, hearing aids and some other electronic medical devices, as it may cause interference to such apparatuses.

➤ INTERFERENCE

The conversation quality of any mobile tablet may be affected by radio interference. An antenna is built inside the mobile tablet and located below the microphone. Do not touch the antenna area during a conversation, lest that the conversation quality deteriorate.

➤ QUALIFIED SERVICE

Only qualified personnel may install or repair tablet equipment. Installing or repairing the mobile tablet on your own may bring great danger and violates the warranty rules.

➤ ACCESSORIES AND BATTERIES

Use only approved accessories and batteries.

➤ USE SENSIBLY

Use only in a normal and proper manner.

➤ EMERGENCY CALLS

Ensure the phone is switched on and in service, enter the emergency number, e.g. 112, then press the Dial key. Give your location and state your situation briefly. Do not end the call until told to do so.

Note: Just like all other mobile tablet, this mobile tablet does not necessarily support all the features described in this manual due to network or radio transmission problems. Some networks even do not support the emergency call service. Therefore, do not rely solely on the mobile tablet for critical communications such as first aid. Please consult the local network operator.

2 Your phone

2.1 Functions of Keys

The mobile tablet provides the following keys:

◆ Power key

Power key situates at the right side of the tablet. While using the tablet, you can press this key to lock screen; if you

press and hold this key, a tablet -options dialog would pop out. Here, you can select to adjust the profile mode, power off, reboot or turn on/off airplane mode.

◆ Volume key

Volume key situates at the left side of the tablet. You can press it to adjust ringer volume.

2.2 Functions of icons

◆ Menu icon

Touch this icon to access options of a selected function;

◆ Home icon

Touch it to open home screen. If you're viewing the left or right extended Home screen, touch it can enter the home screen.

3 Getting started.

3.1 Charging the Battery

- ◆ Your mobile tablet can monitor and display the battery state.
- ◆ Normally the remaining energy of the battery is indicated by the battery level icon at the upper right corner of the display screen.

- ◆ When the battery energy is insufficient, the mobile tablet prompts "Battery low".

Using a travel adapter:

- ◆ Install the battery into the mobile tablet before charging the battery.
- ◆ Connect the adapter of the travel charger with the charging slot in the mobile tablet. Ensure that the adapter is fully inserted.
- ◆ Insert the plug of the travel charger to an appropriate power outlet.
- ◆ During the charging, the battery level grids in the battery icon keep flickering till the battery is fully charged.
- ◆ The battery icon does no longer flicker when the charging process ends.

Note:

Ensure that the plug of the charger, the plug of the earphone, and the plug of the USB cable are inserted in the right direction. Inserting them in a wrong direction may cause charging failure or other problems.

Before the charging, ensure that the standard voltage and frequency of the local mains supply match the rated voltage and power of the travel charger.

Optimizing battery life

You can extend your battery's life between charges by turning off features that you don't need. You can also monitor how applications and system resources consume battery power.

To guarantee the optimal performance of your battery, please stick to the following rules:

- ◆ Turn off radios that you aren't using. If you aren't using Wi-Fi, Bluetooth, use the Setting application to turn them off.
- ◆ Turn down screen brightness and set a shorter screen timeout.
- ◆ If you don't need them, turn off automatic syncing for Gmail, Calendar, and other applications.

3.2 Linking to the Networks and devices

Your tablet can connect to a variety of networks and devices, including mobile networks for voice and data transmission, Wi-Fi data networks, and Bluetooth devices, such as headsets. You can also connect your tablet to a computer, to transfer files from your tablet SD card and share your tablet mobile data connection via USB.

Connecting to Wi-Fi networks

Wi-Fi is a wireless networking technology that can provide Internet access at distances of up to 100 meters, depending on the Wi-Fi router and your surroundings.

Touch Settings>Network> Wi-Fi. Check Wi-Fi to turn it on. The tablet scans for available Wi-Fi networks and displays the names of those it finds. Secured networks are indicated with a Lock icon.

Touch a network to connect to it. If the network is open, you are prompted to confirm that you want to connect to that network by touching Connect. If the network is secured, you're prompted to enter a password or other credentials.

Connecting to Bluetooth devices

Bluetooth is a short-range wireless communications technology that devices can use to exchange information over a distance of about 8 meters. The most common Bluetooth devices are headphones for making calls or listening to music, hands-free kits for cars, and other portable devices, including laptops and cell phones.

Touch Settings> Network > Bluetooth. Check Bluetooth to turn it on.

You must pair your tablet with a device before you can connect to it. Once you pair your tablet with a device, they stay paired unless you unpair them.

Your tablet scans for and displays the IDs of all available Bluetooth devices in range. If the device you want to pair with isn't in the list, make it discoverable.

Connecting to a computer via USB

You can connect your tablet to a computer with a USB cable, to transfer music, pictures, and other files between your tablet SD card and the computer.

3.3 Using the touch screen

◆ Touch-screen tips

➤ Touch

To act on items on the screen, such as application and settings icons, to type letters and symbols using the onscreen keyboard, or to press onscreen buttons, you simply touch them with your finger.

➤ Touch & hold

Touch & hold an item on the screen by touching it and not lifting your finger until an action occurs. For example, to open a menu for customizing the Home screen, you touch an empty area on the Home screen until the menu opens.

➤ **Drag**

Touch & hold an item for a moment and then, without lifting your finger, move your finger on the screen until you reach the target position.

◆ **Lock screen**

When Screen lock in Security setting is enabled, press Power key to lock the handset. This helps to prevent accidental touching of keys and as well as power saving. When Sleep function in Display setting is enabled, after the tablet device has been idle for preset period, the screen will be locked automatically to save power.

3.4 Using the onscreen keypad

You enter text using the onscreen keyboard. Some applications open the keyboard automatically. In others, you touch a text field where you want to enter text to open the keyboard.

◆ **To enter text**

Touch a text field, and the onscreen keyboard opens. Some applications open the keyboard automatically.

◆ **Touch the keys on the keyboard to type.**

The characters you've entered appear in the text field, with suggestions for the word you are typing below.

4Using the Menus

4.1 Backup Restore

You can use this function to backup or restore your tablet data.

4.2 Browser

You can use Browser to view webpages and search for information on the web.

When you open Browser, your home page opens. The web address (URL) of the current page is displayed at the top of the window.

To go to a webpage or search the web

Touch the URL box at the top of the Browser screen. Enter the address (URL) of a webpage. Or enter terms you want to search for. As you enter text, your web search engine makes suggestions of web pages and queries.

To find text on a webpage

Touch Menu icon and touch More > Find on page. Enter the text you're looking for. As you type, the first word with matching characters is highlighted on the screen, and subsequent matches are boxed. Touch the left or right arrow to scroll to and highlight the previous or next matching word..

Downloading files

You can download files and even applications from webpage. The files that you download are stored on your SD card.

To download a file, Different webpage offer different mechanisms for downloading pictures, documents, applications, and other files. Touch & hold an image or a link to a file or to another webpage. In the menu that opens, touch Save. If the file is in a format supported by an application on the tablet, it is downloaded to your SD card. Touch menu icon and then touch More>downloads, here, you can find a list of downloaded files. If you want to delete a file, just touch the indication box which situates at the left of the downloaded file, and an option box will pop out, here, you can select delete to delete an unnecessary file.

4.3 Calculator

You can use this Calculator to solve simple arithmetic problems or use its advanced operators to solve more complex equations.

Enter numbers and arithmetic operators on the basic screen; Drag the basic screen to the left to open the advanced screen; Touch Del to delete the last number or operator you entered. Touch & hold Del to delete everything in the display.

In the calculator screen, you can touch menu icon to access advanced panel.

4.4 Calendar

You can open Calendar to view events you've created.

Touch the Calendar icon in the main menu interface. Events from each Account you've added to your tablet and configured to synchronize calendars are displayed in Calendar.

Creating an event

You can use Calendar on your tablet to create events. In any calendar view, touch menu icon > new event to open a event details screen for a new event.

Enter a name, time, and optional additional details about the event. You can touch plus icon to add more reminders. In the Guests field, you can enter the email addresses of everyone you want to invite to the event. Separate multiple addresses with commas (,). If the people to whom you send invitations use Google Calendar, they'll receive an invitation in Calendar and by email. You can touch menu icon and touch Show extra options to add details about the event. Scroll to the bottom of the Event details screen and touch Done. The event is added to your calendar.

4.5 .Camera

Touch the Camera icon in the main menu interface or on the home screen, camera opens in Landscape mode, ready to take a picture. In this mode, you can touch the camera icon to take a photo, touch photo icon and slide right to switch between photo and video

Note: you can also touch menu icon to pop out an option box. There, you can switch to camcorder mode.

4.6 Clock

Touch the Clock icon on the Home screen or in the main menu interface. You can set an alarm by modifying an existing alarm or by adding a new one. You also can use word time, Timer and Stopwatch.

4.7 Downloads

Through this function, you can view a list of files and applications which you downloaded from the network.

4.8 Email

You use the Email application to read and send email. There are many email address to choose.

Touch email icon to access it. If the Email Account has not been set up, you can set up an Email Account in a few steps.

◆ Account setup

Enter an Email address and the Account's password.

◆ Account settings

- Set inbox checking frequency.
- Set Send email from this Account by default.
- Set Notify me when email arrives.
- Set Synchronize contacts, calendar or Email from this Account.
- Set Automatically download attachments when connected to Wi-Fi.

◆ Compose and sending Email

To compose and send an Email:

1. Touch the create icon to compose a new Email.
2. Enter Email address(es) for intended recipient(s).
3. Touch Menu → Attach file to attach a file.
4. Touch Menu → Add Cc/Bcc to add copy or blind copy this Email to other contacts.
5. After completing the Email, Touch send icon to send the Email. Touch folder icon to check the Account status. For each Email Account there are five default folders, i.e., Inbox, Drafts, Outbox, Send and Trash folders. To view sent Emails, open Sent folder and tap refresh icon.

4.9 Facebook

You can use the Face book through this function after you have a Face book Account and log in it.

4.10 File manager

The tablet supports the SD card. You can use the File Manager to conveniently manage various directories and files on the SD card.

4.11 Google

Stay in the know with the Google app.

4.12 YouTube

See what the world is watching on YouTube.

4.13 Google Play

Google Play is your entertainment unbound. It brings together all of the entertainment you love and helps you explore it in new ways, anytime, anywhere.

4.14 Search

The Search function enables you to open a search box for searching your tablet and the web.

4.15 Settings

The Settings application contains most of the tools for customizing and configuring your tablet.

You can use Wireless Network settings to manage, configure and manage connections to networks and devices by using Wi-Fi. You also can set Bluetooth, data usage, airplane mode, Default SMS app, tethering & portable hotspot .

◆ Battery

You can view your battery status, battery level and battery use in this interface.

◆ Apps

You can use the Applications settings to view details about the applications installed on your tablet, to manage their data and force them to stop, to

view and control currently running services, and to view the storage used by applications, etc..

◆ **Location**

You can turn on/off location and select High accuracy, Battery saving or Device only through this function.

◆ **Language & input**

Use the Language & Keyboard settings to select the language for the text on your tablet and for configuring the input method.

◆ **Date & time**

You can use Date & Time settings to set your preferences for how dates are displayed. You can also use these settings to set your own time and time zone, rather than obtaining the current time from the network.

4.16 Sound Recorder

Use this function to record audio files. Two function icons at the bottom of the Recorder screen are corresponding to start recording and review record file.

4.17 Video player

With Videos, you can play video clips in your device (for example, the video you captured by the camera) or video files stored in compatible SD card (if inserted).

Google, Android, Google Play, YouTube and other marks are trademarks of Google LLC.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These

limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

SAR Information Statement

Your Tablet is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless Tablet employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. * Tests for SAR are conducted with the Tablet transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the Tablet while operating can be well below the maximum value. This is because the Tablet is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna,

the lower the power output. Before a Tablet model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value when worn on the body, as described in this user guide, is 0.48 W/Kg (Body-worn measurements differ among Tablets, depending upon available accessories and FCC requirements). While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this Tablet with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this Tablet is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on

FCC ID: 2AHZ5T30 Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) web-site at <http://www.wow-com.com>. * In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

The SAR test distance is 0mm.

CE Statement

Herby, Shenzhen Huafurui Technology Co., Ltd declares that this Tablet, TAB 30 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

In accordance with Article 10(2) and Article 10(10), this product allowed to be used in all EU member states.

Use the Tablet in the environment with the temperature between -20°C and 25°C

Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss.



Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

The product shall only be connected to a USB interface of version USB2.0

SAR: The device complies with RF specifications when the device used at 0mm from your body.

The highest SAR value for this device when tested for Front-to-face is 0.29 W/Kg, for Limbs is

1.00W/Kg and when worn on the body is 0.98 W/Kg.

RF evaluation distance (Front-to-face) is 10mm

5150-5250 indoor use only.

Adapter shall be installed near the equipment and shall be easily accessible.

The plug considered as disconnect device of adapter

Adapter Model: HJ-FC001K7-EU

Input: AC 100-240V 50/60Hz 0.8A Output: DC 5.0V, 3.0A/ DC 9.0V, 2.0A/ DC 12.0V, 1.5A, 18.0W

Operation Frequency:

For BT/BLE: 2402MHz~2480MHz

For 2.4GWIFI:

2412MHz~2472MHz (802.11b/802.11g/802.11n(HT20))

2422MHz~2462MHz (802.11n(HT40))

For 5G WIFI:

5150MHz~5350MHz, 5725MHz~5875MHz

For FM: 87.5MHz – 108MHz

For GPS: 1.57542GHz

For GSM:

E-GSM 900/GPRS 900/EGPRS 900:

TX: 880MHz~915MHz; RX: 925MHz~960MHz

GSM 1800/GPRS 1800/EGPRS 1800:

TX: 1710MHz~1785MHz; RX: 1805MHz~1880MHz

For WCDMA:

UTRA Band I: TX:1920MHz~1980MHz;

RX: 2110MHz~2170MHz

UTRA Band VIII: TX: 880MHz~915MHz;

RX: 925MHz~960MHz

LTE Band 1: (UL)1920MHz~1980MHz,

(DL) 2110MHz~2170MHz

LTE Band 3: (UL)1710MHz~1785MHz,

(DL)1805MHz~1880MHz

LTE Band 7: (UL)2500MHz~2570MHz,

(DL)2620MHz~2690MHz

LTE Band 8: (UL)880MHz~915MHz,

(DL)925MHz~960MHz

LTE Band 20: (UL)832MHz~862MHz,

(DL) 791MHz~821MHz

Max output power:

BT: 0.002W

BLE: 0.0046W

2.4G WIFI: 0.0565W

5G WIFI: 0.0207W

E-GSM 900/GPRS 900/EGPRS 900: 2.0277W

GSM 1800/GPRS 1800/EGPRS 1800: 0.875W

UTRA Band I: 0.1824W

UTRA Band VIII: 0.2065W

LTE Band 1: 0.1734W

LTE Band 3: 0.1866W

LTE Band 7: 0.1276W

LTE Band 8: 0.2046W

LTE Band 20: 0.1986W

Manufacturer: Shenzhen Huafurui Technology Co., Ltd

Address: Unit 1401 & 1402, 14/F, Jinqi Zhigu Mansion (No. 4 Building of Chongwen Garden), Crossing of the Liuxian Street and Tangling Road, Taoyuan Street, Nanshan District, Shenzhen, P.R. China

E-mail: support@cubot.net

Importer: APEX CE SPECIALISTS LIMITED

Address: UNIT 3D NORTH POINT HOUSE, NORTH POINT, BUSINESS PARK, NEW MALLOW ROAD, CORK, T23 AT2P, IRELAND

DECLARATION OF CONFORMITY

I hereby declare that the product

Product:

Product Name: Tablet

Model: TAB 30

Brand Name: CUBOT

Hardware Version: T30-T618-V1.0

Software Version: CUBOT_TAB_30_P031C_V1.0_20220218

Accessories:

Adapter Information:

Model: HJ-FC001K7-EU

Input: AC 100-240V, 50/60Hz, 0.8A

Output: DC 5.0V, 3.0A/ DC 9.0V, 2.0A/ DC 12.0V, 1.5A, 18.0W

Manufacturer: Shenzhen Huajin Electronics Co., Ltd.

USB Cable Information1:

Model: TAB 30

Length: 1m

Manufacturer: SHENZHEN GYHONTEN ELECTRONICS CO., Ltd

USB Cable Information 2:

Model: TAB 30

Length: 0.1m

Manufacturer: SHENZHEN GYHONTEN ELECTRONICS CO., Ltd

Battery information:

Model:C30

Specification: 3.8V,6580mAh, 25Wh

Manufacturer: SHENZHEN JIAJINYUAN TECHNOLOGY CO.,LTD.

(Name of product, type or model, batch or serial number)

satisfies all the technical regulations applicable to the product within the scope of Council

Directives 2014/53/EU, 2014/35/EU and 2014/30/EU:and declare that the same application has not been lodged with any other notified body.

EN IEC 62368-1:2020+A11:2020

EN 50566:2017

EN 50663:2017

EN 62209-2:2010/A1:2019

EN 62479:2010

ETSI EN 301 489-52 V1.2.1 (2021-11)

Draft ETSI EN 301 489-19 V2.2.0 (2020-09)

ETSI EN 301 489-17 V3.2.4 (2020-09)

Final draft ETSI EN 301 489-3 V2.2.0 (2021-11)

ETSI EN 301 489-1 V2.2.3 (2019-11)

EN55032:2015+A1:2020+A11:2020

EN55035:2017+A11:2020

EN IEC 61000-3-2:2019

EN 61000-3-3:2013+A1:2019

ETSI EN 300 328 V2.2.2 (2019-07)

ETSI EN 301 893 V2.1.1 (2017-05)

ETSI EN 300 440 V2.2.1 (2018-07)

ETSI EN 303 345-1 V1.1.1 (2019-06)

ETSI EN 303 345-3 V1.1.1 (2021-06)

ETSI EN 303 413 V1.2.1 (2021-04)

ETSI EN 301 511 V12.5.1 (2017-03)

ETSI EN 301 908-1 V13.1.1 (2019-11)

ETSI EN 301 908-2 V13.1.1 (2020-06)

ETSI EN 301 908-13 V13.1.1 (2019-11)

(Title(s) of regulations, standards, etc.)

All essential radio test suites have been carried out.

NOTIFIED BODY: MiCOM Labs Inc

– **Address:**

575 Boulder Court,

Pleasanton, California94566

USA

Identification Number: 2280

MANUFACTURER or AUTHORISED REPRESENTATIVE:

– **Address:**

Shenzhen Huafurui Technology Co., Ltd

Unit 1401 & 1402, 14/F, Jinqi Zhigu Mansion (No. 4 Building of Chongwen Garden), Crossing of
the Liuxian Street and Tangling Road, Taoyuan Street, Nanshan District, Shenzhen, P.R. China

This declaration is issued under the sole responsibility of the manufacturer and, if applicable, his authorised representative.


Point of contact:

Bianca.Lei, +860755-83821787 /+860755-23612065

(Name, telephone and fax number)

2022-05-20

(Place, date of issue)



(Signature)

Bianca.Lei, Manager

(Name and title in block letters)

UKCA Statement

This device is in compliance with the essential requirements and other relevant provisions of UK Radio Equipment Regulations (SI 2017/1206); UK Electrical Equipment (Safety) Regulations (SI 2016/1101); and UK Electromagnetic Compatibility Regulations (SI 2016/1091). All essential radio test suites have been carried out.

Operation Frequency:

For BT/BLE: 2402MHz~2480MHz

For 2.4GWIFI:

2412MHz~2472MHz (802.11b/802.11g/802.11n(HT20))

2422MHz~2462MHz (802.11n(HT40))

For 5G WIFI:

5150MHz~5350MHz, 5725MHz~5875MHz

For FM: 87.5MHz – 108MHz

For GPS: 1.57542GHz

For GSM:

E-GSM 900/GPRS 900/EGPRS 900:

TX: 880MHz~915MHz; RX: 925MHz~960MHz

GSM 1800/GPRS 1800/EGPRS 1800:

TX: 1710MHz~1785MHz; RX: 1805MHz~1880MHz

For WCDMA:

UTRA Band I: TX:1920MHz~1980MHz;

RX: 2110MHz~2170MHz

UTRA Band VIII: TX: 880MHz~915MHz;

RX: 925MHz~960MHz

LTE Band 1: (UL)1920MHz~1980MHz,

(DL) 2110MHz~2170MHz

LTE Band 3: (UL)1710MHz~1785MHz,

(DL)1805MHz~1880MHz

LTE Band 7: (UL)2500MHz~2570MHz,

(DL)2620MHz~2690MHz

LTE Band 8: (UL)880MHz~915MHz,

(DL)925MHz~960MHz

LTE Band 20: (UL)832MHz~862MHz,

(DL) 791MHz~821MHz

Max output power:

BT: 0.002W

BLE: 0.0046W

2.4G WIFI: 0.0565W

5G WIFI: 0.0207W

E-GSM 900/GPRS 900/EGPRS 900: 2.0277W

GSM 1800/GPRS 1800/EGPRS 1800: 0.875W

UTRA Band I: 0.1824W

UTRA Band VIII: 0.2065W

LTE Band 1: 0.1734W

LTE Band 3: 0.1866W

LTE Band 7: 0.1276W

LTE Band 8: 0.2046W

LTE Band 20: 0.1986W

Manufacturer: Shenzhen Huafurui Technology Co., Ltd

Address: Unit 1401 & 1402, 14/F, Jinqi Zhigu Mansion (No. 4 Building of Chongwen Garden), Crossing of the Liuxian Street and Tangling Road, Taoyuan Street, Nanshan District, Shenzhen, P.R. China

E-mail: support @cubot.net

Importer: APEX CE SPECIALISTS LIMITED

Address: 89 Princess Street, Manchester, M1 4HT, UK

DECLARATION OF CONFORMITY

I hereby declare that the product

Product:

Product Name: Tablet

Model: TAB 30

Brand Name: CUBOT

Hardware Version: T30-T618-V1.0

Software Version: CUBOT_TAB_30_P031C_V1.0_20220218

Accessories:

Adapter Information:

Model: HJ-FC001K7-EU

Input: AC 100-240V, 50/60Hz, 0.8A

Output: DC 5.0V, 3.0A/ DC 9.0V, 2.0A/ DC 12.0V, 1.5A, 18.0W

Manufacturer: Shenzhen Huajin Electronics Co., Ltd.

USB Cable Information1:

Model: TAB 30

Length: 1m

Manufacturer: SHENZHEN GYHONTEN ELECTRONICS CO., Ltd

USB Cable Information 2:

Model: TAB 30

Length: 0.1m

Manufacturer: SHENZHEN GYHONTEN ELECTRONICS CO., Ltd

Battery information:

Model: C30

Specification: 3.8V, 6580mAh, 25Wh

Manufacturer: SHENZHEN JIAJINYUAN TECHNOLOGY CO., LTD.

(Name of product, type or model, batch or serial number)

satisfies all the technical regulations applicable to the product within the scope of UK Radio Equipment Regulations (SI 2017/1206); UK Electrical Equipment (Safety) Regulations (SI 2016/1101); and UK Electromagnetic Compatibility Regulations (SI 2016/1091) and declare that the same application has not been lodged with any other UK Approved

Body.

BSEN IEC 62368-1:2020+A11:2020

EN 50566:2017

EN 50663:2017

EN 62209-2:2010/A1:2019

EN 62479:2010

ETSI EN 301 489-52 V1.2.1 (2021-11)

Draft ETSI EN 301 489-19 V2.2.0 (2020-09)

ETSI EN 301 489-17 V3.2.4 (2020-09)

Final draft ETSI EN 301 489-3 V2.2.0 (2021-11)

ETSI EN 301 489-1 V2.2.3 (2019-11)

BSEN55032:2015+A1:2020+A11:2020

BSEN55035:2017+A11:2020

BSEN IEC 61000-3-2:2019

BSEN 61000-3-3:2013+A1:2019

ETSI EN 300 328 V2.2.2 (2019-07)

ETSI EN 301 893 V2.1.1 (2017-05)

ETSI EN 300 440 V2.2.1 (2018-07)

ETSI EN 303 345-1 V1.1.1 (2019-06)

ETSI EN 303 345-3 V1.1.1 (2021-06)

ETSI EN 303 413 V1.2.1 (2021-04)

ETSI EN 301 511 V12.5.1 (2017-03)

ETSI EN 301 908-1 V13.1.1 (2019-11)

ETSI EN 301 908-2 V13.1.1 (2020-06)

ETSI EN 301 908-13 V13.1.1 (2019-11)

(Title(s) of regulations, standards, etc.)

All essential radio test suites have been carried out.

NOTIFIED BODY: MiCOM Labs Inc

– **Address:**

575 Boulder Court,

Pleasanton, California94566

USA

Identification Number: 2280

MANUFACTURER or AUTHORISED REPRESENTATIVE:

– **Address:**

This declaration is issued under the sole responsibility of the manufacturer and, if applicable, his authorised representative.


Point of contact:

Bianca.Lei, +860755-83821787 /+860755-23612065

(Name, telephone and fax number)

2022-05-20

(Place, date of issue)



(Signature)

Bianca.Lei, Manager

(Name and title in block letters)



BE	BG	CZ	DK	DE	EE	IE	EL
ES	FR	HR	IT	CY	LV	LT	LU
HU	MT	NL	AT	PL	PT	RO	SI
SK	FI	SE	NO	IS	LI	CH	TR

In all EU member states, operation of 5150-5350 MHz is restricted to indoor use only.